

SYSTEM 600 LOADING INSTRUCTIONS



STEP 1

Open the dispenser using the key



STEP 2

Insert the first roll into the dispenser



STEP 3

Insert the second roll into the dispenser



STEP 4

Pull the end of the first roll out of the dispenser



STEP 5

Shut the dispenser front